

# xpress STEP™

## SPRAY FLOORING ADHESIVE

### PRODUCT FEATURES

- Faster installation time
- Open to traffic immediately after installation
- Heat weld in 1 hour for Sheet Vinyl
- May be used under hospital beds
- Low VOC/low odor
- For use with Mannington Luxury Vinyl Tile/Planks, Infinity Carpet Tile, Sheet Vinyl and VCT.
- FloorScore Certified



### PRODUCT SPECS

#### XpressStep for Sheet Vinyl

**RH:** 90% **MVER:** 8 **pH:** 10  
**COVERAGE:**  
 150-185 FT<sup>2</sup> (14-17.2 M<sup>2</sup>)  
**SKU:** 803950

#### XpressStep PREMIUM for LVT

**RH:** 93% **MVER:** 10 **pH:** 12  
**COVERAGE:**  
 100-125 FT<sup>2</sup> (9.3-11.6 M<sup>2</sup>)  
**SKU:** 804876

#### XpressStep for LVT & Infinity Carpet Tile

**RH:** 90% **MVER:** 8 **pH:** 11  
**COVERAGE:**  
 150-185 FT<sup>2</sup> (14-17.2 M<sup>2</sup>)  
**SKU:** 803881

#### XpressStep for VCT

**RH:** 90% **MVER:** 8 **pH:** 11  
**COVERAGE:**  
 170-200 FT<sup>2</sup> (15.8-18.6 M<sup>2</sup>)  
**SKU:** 855396



### INSTALLATION NOTES

- Use XpressStep for speed and ease of installation. Proper floor prep and correct spray pattern are key for best performance/amount.
- Detailed installation instructions are located on spray can label.
- Pre-installation site visits and installation training are available for jobs of 1000 YO<sup>2</sup> or more.