

- **Radiant Heat:** Mannington Commercial resilient sheet flooring can be installed over radiant heating (hydroponic) systems. The maximum temperature of the subfloor surface must not exceed 85°. Before installing flooring products over newly constructed radiant-heating system, set the thermostat to a comfortable room temperature for the installation. For existing systems, the system must be switched off for a minimum of 48 hours before, during and 48 hours after flooring installation.
- **Direct Sunlight:** Installations in areas where there is heavy direct sunlight exposure for long periods of times should utilize window treatments and/or Mannington's V-95 two-part urethane adhesive in these areas.
- **Protecting New Installations:** New installations must be protected while the adhesive cures. Early foot traffic, point, or rolling loads can cause adhesive displacement or breaking of the bond between the adhesive and the sheet or substrate.

REPAIRS

Replacing Damaged Areas

- If possible, the floor covering repair piece should come from the original installation. Typically, consumers retain leftover pieces from the original installation for attic stock.
- Tape the repair piece over the damaged area and double-cut using a steel square as a guide.
- Remove the damaged area and scrape the subfloor clean. Apply adhesive on the back of the repair piece and insert into the flooring.
- Roll the repair piece with a hand seam roller.
- Use the appropriate Mannington seam sealer to seal all cuts.

Choices that Work.

For more information, please contact Mannington Technical Services at 800 241 2262 Ext. 3 or visit www.manningtoncommercial.com.