

Mannington FreLock Tabs

Adhesive Free Installation Facts

For an “adhesive free” installation where there is a need for no “wet” adhesives.

- FreLock Tabs are intended for use with Infinity Modular, and Infinity RE modular backings only.
- FreLock Tabs are acrylic pressure sensitive tape.
- FreLock Tabs can be used:
 - Where “wet” adhesives are not approved
 - Temporary installations
 - Where existing flooring needs to be adhesive free for future reuse
 - And, do it yourself projects
- Installation
 - A clean, dust free, dry sub-floor
 - The tape must contact with two of the four module sides to assure tiles do not shift under heavy traffic
 - Can be bonded to the floor or free floating
 - No mess, no solvent or water clean up required
 - Low odor and low VOC
- Specifications
 - 3 inches wide
 - 108 feet per roll
 - Coverage: Monolithic and Quarter Turn - 50-55 sq. yds. Per roll
Horizontal Ashlar (Brick) - 40-45 sq. yds. Per roll

