

4. **Surface Flatness for all Subfloors: The surface shall be flat to 3/16 (3.9mm) in 10 ft. (3050 mm) and 1/32" (0.8 mm) in 1 ft (305 mm)** To check flatness, place a 10 ft straight edge, string, laser level or use another suitable method on the surface and measure the gap.
5. **Concrete Subfloors:**
 - a. **Concrete subfloors must be finished and cured, free of all sealers, coatings, finishes, dirt, film forming curing compounds, or other substances that may prevent proper bonding of the flooring materials (ACI 302.1 and ASTM F710).**
 - b. Randomly check concrete subfloor for porosity using the drop water test. Place a 1 inch diameter drop of water directly onto the concrete subfloor. If the water droplet does not dissipate within 60 to 90 seconds the subfloor is considered non-porous.
 - c. Concrete subfloors must have a minimum compressive strength of 3000 psi. Concrete subfloors shall not consist of lightweight concrete or gypsum.
 - d. Moisture Testing: Perform either the preferred In-situ Relative Humidity (RH) Test (ASTM F2170) or the acceptable Moisture Vapor Emission Rate (MVER) Test (ASTM F1869). For acceptable moisture limits please refer to the specifications of the adhesive of choice.
 - e. Alkalinity: Must test surface alkalinity (ASTM F710). A 7.0 to 9.0 pH is acceptable.
6. Wood Subfloors and underlayment panels shall have the moisture content tested using a suitable wood pin meter. Readings between the wood subfloor and underlayment should be within 3% and have a maximum moisture content of 14% or less.

MOISTURE SUPPRESSANT SYSTEM

Concrete subfloors that exceed adhesive specifications will require a Moisture Suppressant System. Due to complexities associated with moisture vapor transmission, emissions and movement of soluble salts (alkalinity) in concrete subfloors, we do not offer, recommend, or warranty a specific solution for excess moisture in concrete slabs. However, there are many companies that offer solutions with warranties for excess moisture in concrete slabs.

Mannington Commercial suggests that you reference the current ASTM F710, "Standard Practice for Preparing Concrete Floors to Receive Resilient Flooring" and ASTM F301 Standard Practice for Two Component Resin Based Membrane Forming Moisture Mitigation Systems for Use Under Resilient Flooring Systems. Contact one or more of the following or other moisture suppressant system suppliers for assistance:

Ardex (724) 203-5000 www.ardex.com
Koester American Corp. (757) 425-1206 www.koesterusa.com
Mapei (800) 426-2734 www.mapei.com
Uzin Ltd. (800) 505-4810 www.ufloorsystems.com
Schönox(855) 391-2649 www.hpsubfloors.com

SUBFLOOR PREPARATION

Concrete

Careful subfloor preparation is vital for an excellent floor appearance and good tile/plank adhesion. The subfloor must be smooth, firm, flat, clean, dry, free from defects, and fit for purpose. A suitable smoothing compound should be used to ensure that no irregularities show through to the surface of the finished floor. In all cases, the subfloor must meet the moisture and pH requirements before installation.

Below and On-grade concrete subfloors must have a suitable vapor retarder properly installed directly beneath the slab. Always follow manufacturers' written recommendations for the use and installation of their appropriate surface preparation materials.

1. Record and file site conditions, test results and any corrective action(s) taken. It is important to maintain this documentation throughout the warranty period.
2. Subfloor must be clean (free of dirt, sealers, curing, hardening or parting compounds or any substance that may stain or prevent adhesion), smooth, flat, sound, fit for purpose, free of movement, excessive moisture and high alkalinity.
3. Slick surfaces such as power troweled concrete shall be abraded or profiled to allow for a mechanical bond between the adhesive and subfloor.

Choices that Work.

For more information, please contact Mannington Technical Services at 800 241 2262 Ext. 3 or visit www.manningtoncommercial.com.

INSTALLATION PROCEDURES

Before starting the Mannington Luxury Vinyl Flooring (LVF) – (LVT or LVP) installation, ensure the following are satisfactorily completed.

- **Acclimation:** The installation area and materials to be installed shall be maintained at a minimum of 65°F(18.3°C) and a maximum of 85°F (29.4°C) for 48 hours before, during and for 48 hours after completion of the installation. Relative humidity level extremes should also be avoided. General recommended humidity control level is between 35 – 55 %. If a system other than the permanent HVAC source is utilized, it must provide proper control of both temperature and humidity to recommended or specific levels for the appropriate time duration.
- **Flooring Materials:** Check quantity of Mannington LVF and adhesive are sufficient for area to be installed. Check tile for visual defects before installation. Installation of flooring acknowledges acceptance of materials. Report discrepancies immediately to Mannington at 1 800 241 2262 EXT 2 (Claims) for installation of products installed with visual defects or incorrect style will not be honored.
- **Expansion joints, isolation joints, or other moving joints** are incorporated into concrete floor slabs in order to permit movement without causing random cracks in the concrete. These joints must be honored and not be filled with underlayment products or other materials, and floor coverings must not be laid over them. Expansion joint covering systems should be detailed by the architect or engineer based upon intended usage and aesthetic considerations.
- **Surface cracks, grooves, depressions, control joints or other non-moving joints, and other irregularities** shall be filled or smoothed with high quality Portland cement based patching or underlayment compound for filling or smoothing, or both. Patching or underlayment compound shall be moisture, mildew, and alkali-resistant, and shall provide a minimum of 3000 psi compressive strength after 28 days, when tested in accordance with ASTM C109 or ASTM C472, whichever is appropriate.
- **Subfloor Preparation:** Make sure all surfaces to be covered are completely clean, dry and smooth and that all necessary subfloor preparation has been properly completed and documented.
- **Inspect Substrate:** Perform final acceptance inspection of substrate.
- **Adjacent Surfaces Protection:** Protect adjacent work areas and finish surfaces from damage during product installation.
- **Flooring Protection:** Mannington LVF should be the last material installed to prevent other trades from disrupting the installation and adhesive set-up or damaging the floor.

Start of flooring installation indicates acceptance of current subfloor conditions and full responsibility for completed work.

Mannington LVF products have arrows imprinted on the back. Lay all arrows pointing in the same direction. Mannington LVF comes in plank and square tile formats. Mannington LVF can be laid out to run either parallel or diagonal to the room or primary wall.

- Tiles should be installed running in the same direction (block or staggered), when quarter turned, arrows should alternate.
- Plank flooring should have end joints offset by at least 6” and staggered to create a random appearance that avoids alignment of end joints. (All arrows pointing in the same direction).

The following conditions must be given consideration when determining how the Mannington LVF will be installed:

1. Layout: Layout shall be specified by end user, architect or designer.

- a. Establish center marks and determine start point to balance installation in room and have equal tile widths on opposite sides of room. This can be facilitated by dry laying tiles and marking base lines.
- b. The room layout must be set-up so that all flooring can be installed while staying off freshly installed tiles. This will minimize tile shifting, adhesive displacement and wet adhesive from oozing up and getting onto the face of the tiles. This can be accomplished by creating work zones outlined with chalk lines to spread adhesive aligned with established base lines. Create work zones that are no wider than the installers comfortable arm reach and in multiples of the tile width.
- c. All Installations: Spread only the amount of adhesive that can be covered within the working time specific to the adhesive being used.

When all preparatory work is satisfactorily completed, including dry fitting cut tiles (if applicable), proceed with installation. Inspect each tile for visual defects before installing. **Installation of the flooring implies acceptance of materials.**

Choices that Work.

For more information, please contact Mannington Technical Services at 800 241 2262 Ext. 3 or visit www.manningtoncommercial.com.

Adhesives: Mannington Commercial recommends the following adhesives for the installation of Mannington Commercial LVF. Only these adhesives should be used. Other adhesives may not provide adequate performance and could result in a failure.

IMPORTANT NOTE: Mannington adhesives are specifically formulated to be fully compatible with backings, chemistry and to maximize the performance of Mannington products. Using substitutes or failing to use Mannington adhesives as recommended can cut short product life, cause installation failure and/or lead to a chemical reaction such as hydrolysis which will permanently damage the backing and **will void all applicable warranty coverage.**

- 1. Mannington Commercial V-82 Adhesive:** Solvent-free, acrylic adhesive for installation of Mannington Commercial LVF on porous substrates including concrete that is dry per ASTM F-1869 3 lbs maximum MVER or ASTM F-2170 75% maximum relative humidity. V-82 should be applied with a trowel 1/16 wide x 1/32 deep and spaced 1/32 apart. Spread rate approximately 150 – 200 sq ft per gallon. See adhesive label for details.
- 2. Mannington M-Guard V-88 Adhesive:** Moisture resistant transitional pressure sensitive adhesive is recommended for higher moisture tolerance of 12 lbs maximum MVER or 99% relative humidity. Maximum pH of 12. M-Guard V-88 adhesive will not correct pre-existing moisture problems in older concrete subfloors. V-88 should be applied with 1/16 wide x 1/32 deep and spaced 1/32 apart U notched trowel for porous substrates and a 1/16 wide x 1/32 deep and spaced 5/64 apart U notched trowel for non-porous substrates. Porous spread rate approximately 250 sq ft per gallon. Non-porous spread rate 350 sq ft per gallon. For non-porous substrates adhesive must dry completely. See adhesive label for details.
- 3. Mannington Commercial V-95 adhesive:** Solvent-free two-component, epoxy for use on non-porous substrates, under hospital beds, operating room tables, heavy rolling loads, areas subject to standing water, topical moisture or where high performance is needed. Moisture limits are per ASTM F-1869 3 lbs maximum MVER or ASTM F-2170 75% maximum relative humidity. V-95 should be applied with a 1/16 wide x 1/32 deep and spaced 1/32 apart. Spread rate approximately 185 – 245 sq ft per gallon. See adhesive label for details.
- 4. XpressStep Premium Spray Adhesive:** Water based spray adhesive recommended for the installation of Mannington Commercial LVF over porous and non-porous substrates. Moisture limits are 12 lbs maximum MVER or 98% relative humidity. Maximum pH of 12. Spread rate approximately 150 – 185 sq ft per can.
XpressStep Spray Adhesive: Moisture limits are 10 lbs MVER or 95 % relative humidity. Maximum pH of 11. Spread rate approximately 150 – 185 sq ft per can.
XpressStep Spray Adhesives may be used under hospital beds, operating room tables and heavy rolling loads.

Mannington Commercial will not assume responsibility for floor covering failure due to hydrostatic pressure or moisture vapor emission. The final responsibility for determining if the concrete is dry enough for installation of the flooring lies with the floor covering installer.

CAUTION: Temperature directly affects adhesive working and setting times. Warmer temperatures shorten working times and colder temperatures lengthen working times of adhesive. Follow instructions on container for proper application.

Choices that Work.

For more information, please contact Mannington Technical Services at
800 241 2262 Ext. 3 or visit www.manningtoncommercial.com.

Adhesive Application: Follow the instructions on the adhesive labels.

- a. Use a trowel with appropriate notch size. Do not use worn trowels (approximately 600 sf usage on concrete).
- b. Spread adhesive evenly with proper trowel held at 60 degree angle avoiding skips or voids and excessive adhesive application.
- c. Only spread sufficient adhesive that can be covered within the adhesive working time.
- d. Tiles/Planks must be placed into adhesive as specified (follow label directions).
- e. Install rows to chalk line making sure tiles/planks are precisely aligned with chalk line and adjacent tiles.
- f. Randomly check tiles/planks for complete coverage of adhesive onto back of tile especially near the end of each adhesive spread. If there is little or no adhesive transfer, or if the adhesive has flashed off or skinned over; adequate bonding may not be possible. Scrape the flashed off adhesive from the floor and spread fresh adhesive.
- g. If tiles/planks shift, use releasable masking tape diagonally over seams to keep tiles tight and aligned.
- h. Wet-Set Application: Do not work on top of freshly installed flooring. This will minimize tile/plank shifting, adhesive displacement, and prevent wet adhesive from oozing up and getting onto the surface of the new flooring. If you must work on top of newly installed flooring, use kneeling and or walk boards.
- i. The floor must be rolled in both directions using a 100 lb 3-section roller. Roll floor as soon as conditions permit without the tiles/planks sliding or adhesive bleeding to the surface. Roll floor again 90 degrees to the first within 1 hour. Mannington Commercial's V-95 and V-82 adhesives should provide 100% uniform adhesive transfer (no visible trowel ridges) onto the back of the tile/plank (and not cause adhesive to squeeze out between tiles/planks). Pressure Sensitive Adhesive will not transfer 100% to the backing of the tile/plank. Be sure not to exceed the 3 hour working time.
- j. Clean excess adhesive as you install before it is allowed to dry. Use a soapy clean soft cloth to remove wet excess adhesive.
- k. Clean up all debris as you work.
- l. Wait 24 hours for normal foot traffic and wait 48 hours for point and rolling loads after installation.
- m. During first five days minimize heavy wet cleaning to allow adhesive to fully set.

Special Considerations:

- a. Radiant Heat: Mannington Commercial LVF can be installed over Radiant heating (hydroponic) systems. The maximum temperature of the subfloor surface must not exceed 85°. Before installing flooring products over newly constructed radiant-heating systems, operate the system at maximum capacity to force any residual moisture from the cementitious topping of the radiant-heating system. Then set the thermostat to a comfortable room temperature for the installation. For existing systems the system must be switched off for a minimum of 48 hours before, during and 48 hours after flooring installation.
- b. Direct Sunlight: Installations in areas where there is heavy direct sunlight exposure for long periods of time should utilize window treatments and/or utilize Mannington's V 95 two part urethane adhesive in these areas.
- c. Protecting New Installations: New Installations must be protected while the adhesive cures. Early foot traffic, point or rolling loads can cause adhesive displacement or breaking of the bond between the adhesive and the tile or substrate.

ROUTINE MAINTENANCE

To get your new Mannington Commercial floor looking its best, and to keep it that way, Mannington Commercial recommends the following initial maintenance procedures. For detailed recommendations, see the Mannington Maintenance Instructions.

- Use non-staining matting system at exterior doors that is appropriate for soil load and weather conditions.
- Use appropriate floor protectors, glides and wheels and do not drag or slide objects across the surface of the floor.
- Do not use abrasive cleaners that can scratch the floor surface or detergent cleaners that leave a residue.

Day 1

- Stay off the new floor. Minimize traffic.

Day 2 to 4

- Dust mop, sweep or vacuum the floor to remove loose dirt and grit.
- Lightly damp mop (well wrung out mop) floor with properly diluted Neutral cleaner solution.

Day 5

- Choose from multiple routine maintenance options to suit individual circumstances and end user preference.

Choices that Work.

For more information, please contact Mannington Technical Services at 800 241 2262 Ext. 3 or visit www.manningtoncommercial.com.

MAINTENANCE PRECAUTIONS AND SAFETY INFORMATION

Effective maintenance includes promptly removing all spills and then thoroughly cleaning with a diluted neutral cleaner or cleaner/maintainer solution. Failure to establish an effective routine maintenance program will not only detract from the appearance of the floor but may shorten its useful life.

SAFETY FIRST: Before commencing work, put out signs or safety cones to warn that cleaning is in progress. A slippery floor can cause accidents. This can be caused by poor maintenance, surface contamination, spills or when the floor is wet. All hard floors can be slippery when wet. Ensure the floor is clean and dry before resuming use. **Use warning signs in commercial areas when performing maintenance or cleaning spills.**

Choices that Work.

For more information, please contact Mannington Technical Services at 800 241 2262 Ext. 3 or visit www.manningtoncommercial.com.